

HOW TO E-CLEAN

“E-CLEAN a minimum of every 2 weeks or twice a month”.


- Power off, then unplug the machine



- Unlock (turn left) the filter ring lock and remove HG filter



- Always check the O-ring and place back on HG filter



- Put 1(one) sachet of e-clean powder in CPU – (cleaning portable unit).



- Install the CPU then lock, turn ring to the right to install



- Turn on the faucet. When the water starts to flow from the flex hose, count to 10 and then turn off the faucet.
- Place the flex hose & grey hose in a glass. Allow the water to partially fill the glass.



- Leave the flex hose and grey hose for 4 to 5 hours.
- Remove the glass, arrange the hoses, turn on the faucet and let the water run for 5 minutes.
- Remove CPU, unscrew and let dry. Place HG filter and lock into place (turn right).



- Plug machine in, turn power on, e-clean is complete.

Enagic Philippines Inc.

**Unit 3 and 4, 16F A.T. Yuchengco
Centre 26th and 25th Streets,
Bonifacio Global City, 1634,
Taguig City
Tel: 8519 5508**